


Zoom Tool

Zoom dropdown consists of different zoom sizes for the viewport, with 20X zoom as default size. User can click on the dropdown arrow to access other zoom options.



From:

<https://docs.pathomation.com/pimsls/3.0.0/> - PIMS LS 3.0.0

Permanent link:

<https://docs.pathomation.com/pimsls/3.0.0/doku.php?id=zoom&rev=1747060249>

Last update: **2025/05/12 17:30**

