Panels layout (administration)

This page allows us to set the default panel layout for PMA. Studio viewer. Viewer panel consists of one or more viewports organized in grid and toolbar underneath it. Almost every section of PMA. Studio frontend has its own panel that allows user to easily interact and make changes accordingly.

```
Edit Panels Layout

PATHOMATION

Tile Servers

Security

Security

Panels Layout hasHeaders="true"
reorderEnabled="false"
selectionEnabled="false"
showPopoutIcone"false"
showIoseIcon="true"
showLayout
File type="column" width="85">
(Item type="column" width="85">
(Item type="column" width="15">
(Item type="column" wi
```

From:

https://docs.pathomation.com/pimsls/3.0.1/ - PIMS LS 3.0.1

Permanent link:

https://docs.pathomation.com/pimsls/3.0.1/doku.php?id=admin_panels&rev=1648660501

Last update: 2022/03/30 20:15

