


# Configure

The Configure tab contains icons for configuring your cockpit.

You can connect to various types of storage including local storage via [PMA.start](#), and [My Pathomation](#) if you have an account - if you don't have one already then please sign up, your first 10 GB is free!

You can also manage all of the many possible panels in PIMS LS, as well as quickly jump to pre-set layouts of panels and toggle on/off Viewport elements e.g. the slide overview.



From:  
<https://docs.pathomation.com/pimsls/3.0.1/> - **PIMS LS 3.0.1**

Permanent link:  
<https://docs.pathomation.com/pimsls/3.0.1/doku.php?id=configure&rev=1733316223>

Last update: **2024/12/04 15:43**

