

## Grid: Slide Tool Group

The Slide toolgroup contains tools for turning changing brightness/contrast of your current image, rotating and magnifying the slide.



### Top Row

1. Brightness/contrast adjuster
2. Flip/Rotate dropdown - opens a dropdown menu with all rotation commands
3. Pop out selected/current slide
4. Send current slide to Tray [read more about trays here](#)

From:

<https://docs.pathomation.com/pimsls/3.0.1/> - PIMS LS 3.0.1

Permanent link:

<https://docs.pathomation.com/pimsls/3.0.1/doku.php?id=slide&rev=1731937245>

Last update: **2024/11/18 16:40**

