


# Administration

This is the administrative end of PMA.Studio where you can configure and handle important aspects of PMA.Studio viewer area. This includes global settings, PMA.core servers, security, shared links, conference settings, server visits, system users and lot more.



PATHOMATION

- 🏠 Tile Servers
- 🔒 Security
- 📄 Layout
  - 📄 Panels Layout
  - ☰ Ribbon Layout
- 👤 Users
- 📄 Settings
  - ⚙️ Global Settings
  - 📞 Conference Settings
- ☰ Logs
  - ↪️ Shared Links
  - 👤 Server Visits
  - ☰ Elmah Logs
- 📄 Docs
  - 📄 Manual
  - 📄 Swagger Docs
- 🖼️ Viewer

## Configure server connectivity

## Interface and visualization

## Security settings

## Logging and troubleshooting

From:

<https://docs.pathomation.com/pimsls/3.1.0/> - **PIMS LS 3.1.0**

Permanent link:

<https://docs.pathomation.com/pimsls/3.1.0/doku.php?id=admin&rev=1660037580>

Last update: **2022/08/09 12:33**

