


Other Tools

Add/Remove Row - Add/Remove Columns






These tools allows us to add new rows to the current grid, delete rows, and add or remove new columns. This allows user to open up multiple slides in a grid view.



Grid snapshot



This tool allows user to take snapshot of the whole grid. On clicking the icon, a popup shows up that allows user to selected different options like annotations, barcode, labels to be part of the grid snapshot.



From:

<https://docs.pathomation.com/pimsls/3.1.0/> - PIMS LS 3.1.0

Permanent link:

https://docs.pathomation.com/pimsls/3.1.0/doku.php?id=other_grid_tools

Last update: 2025/05/12 18:25

