


## Grid: Synchronize Tool Group

The Synchronize toolgroup contains tools for turning on synchronised viewing and some grid management tools.



### Synchronized viewing

Turning on the Sync icon when you have 2 or more cells open in your grid will trigger synchronised viewing, you can see a quick video of this below:

[pimsls\\_syncviewing.mp4](#)

The other functions are:

1. Clear all grid cells
2. Clear current cell
3. Open current slide/cell in a new viewport tab in a 1x1 grid

From:

<https://docs.pathomation.com/pimsls/3.1.0/> - PIMS LS 3.1.0

Permanent link:

<https://docs.pathomation.com/pimsls/3.1.0/doku.php?id=synchronize&rev=1731936261>

Last update: 2024/11/18 16:24

