

This is the administrative end of PMA.Studio where you can configure and handle important aspect relating to PMA.Studio viewer area. This includes global settings, PMA.core servers, security, shared links, conference settings, server visits, system users and lot more.



PATHOMATION

- 🏠 **Tile Servers**
- 🔒 **Security**
- 📄 **Layout**
 - 📄 **Panels Layout**
 - ☰ **Ribbon Layout**
- 👤 **Users**
- 📄 **Settings**
 - ⚙️ **Global Settings**
 - 📞 **Conference Settings**
- ☰ **Logs**
 - ↪️ **Shared Links**
 - 👤 **Server Visits**
 - ☰ **Elmah Logs**
- 📄 **Docs**
 - 📄 **Manual**
 - 📄 **Swagger Docs**
- 🖼️ **Viewer**

From:

<https://docs.pathomation.com/pimsls/3.1.1/> - **PIMS LS 3.1.1**

Permanent link:

<https://docs.pathomation.com/pimsls/3.1.1/doku.php?id=admin&rev=1648583518>

Last update: **2022/03/29 22:51**

