

Who should read this

Any end user who wants to transfer slide between a local site ([PMA.start](#)) and a remote one ([PMA.core](#) or [My Pathomation](#)) or between two remote servers ([PMA.core](#) and [My Pathomation](#) interchangeably).

Users that are primarily focused on [My Pathomation](#) should also have a look at the recent upload capabilities added to [PMA.start](#). PMA.transfer relies on [PMA.start](#) anyway, and for many simple straightforward scenarios, the built-in functionalities of [PMA.start](#) (or even upload functions in [My Pathomation](#) itself) may be sufficient.

From:

<https://docs.pathomation.com/pma.transfer/> - **PMA.transfer**

Permanent link:

https://docs.pathomation.com/pma.transfer/doku.php?id=who_should_read_this

Last update: **2021/07/08 15:40**

